MEYERTECH
SECURITY with VISION

Software Upgrade

ZoneVu

DVK-001/ZVK-002 Operator Keyboard

This document details the procedure for upgrading equipment firmware/software.



1. Unplug the DVK-001.
2. Remove bottom of the box to gain access.
3. Locate DVK-001 CPU Module EPROM.
4. Note Orientation of the EPROM, and replace with the upgrade, ensuring all pins are firmly in place.
5. Power up DVK-001. Defaults will be loaded automatically.
6. Replace cover.
7. Power on the DVK-001
8. Logon as a Manager.
9. Calibrate joystick - Hold down **F1** key, select **Setup Keyboard**, select **Calibrate Joystck**.

N.B. After upgrading, the keyboard will have a default MAC (address) of 1. If there are several keyboards on the system, the MAC **must** be correctly reset.

EEPROM Label

K1GEN001 V1.34.0.1 2F10

MEYERTECH
OFFICE BLOCK ONE
SOUTH LINK BUSINESS PARK
OLDHAM OL4 1DE

TEL +44 (0) 161 628 8406
FAX +44 (0) 161 628 9811
Email sales@meyertech.co.uk
http://www.meyertech.co.uk